



Montaj ve Kablolama

The diagram illustrates the Sens module, a rectangular device with a white faceplate. At the top left, a red line points to a screw terminal labeled "Giriş LED'i" (Input LED). Below this, a screw terminal is labeled "L1". At the top right, another screw terminal is labeled "L2". The center of the faceplate features the "SENS" logo. Below the logo, a horizontal row of 12 pins is numbered 1 through 12. On the far left and right of this row are two circular screw terminals, each with a red line pointing to it and the label "Vida yeri" (Screw hole). At the bottom of the module, a green PCB is visible with 12 pins. Red lines connect these pins to labels: "IN+" (pin 1), "OUT+" (pin 2), "IN-" (pin 3), "OUT-" (pin 4), "Input+" (pin 5), and "Input-" (pin 6). The remaining pins (7-12) are not labeled.

-
- The diagram shows a 12-channel relay module with a 5V voltage regulator. The module has two power input terminals, L1 and L2, and a 5V output terminal. A 5V regulator is connected to the L1 and L2 terminals. The module has 12 channels, each with a relay. The relays are connected to a common terminal (COM) and a normally open terminal (NO). The relays are connected to a 5V supply and a ground terminal. The module is labeled "SENS" and "5V".
- Below the module, a circuit diagram shows a relay connected to a 5V supply and a ground terminal. The relay is connected to a common terminal (COM) and a normally open terminal (NO). The relays are connected to a 5V supply and a ground terminal. The module is labeled "SENS" and "5V".

Test İşlemi

- ◆ M1-AIM-300 giriş modülüne, el tipi programlayıcı kullanarak adres atayın.
- ◆ Modülü SENS adreslenebilir panelin loop hattına bağlayın.
- ◆ Kontrol panelini açın, modülü ayarlar bölümünden manuel ya da otomatik olarak yapılandırın ve panele ekleyin.
- ◆ Modül kontrol paneli tarafından tanındıktan sonra, modülün LED'i yanıp sönmeye başlayacaktır.

- ◆ Pakette bulunan 10k ohm'luk direnci, sonlandırma direncine paralel olacak şekilde bağlayın. Bu durumda panel yangın durumunu göstermelidir.
- ◆ Eğer sonlandırma direnci devresi açılırsa ya da hat kısa devre yapılırsa, panelde arıza modu görünmelidir.

Çalışma Modları

Normal	LED yanıp sönüyor.
Alarm	LED sürekli yanıyor.
Hata	LED sürekli yanıyor.

Garanti

Bu cihazın yalnızca uyumlu bir kontrol paneli ile kullanıldığından ve üzerinde herhangi bir zarar verici işlem yapılmadığından emin olun; aksi takdirde garanti kapsamında değerlendirilmez. Ürünlerin düzgün çalışmasını sağlamak için düzenli olarak kontrol edilmesi, bakımı ve servisi yapılması gerekmektedir.

Troubleshooting

Giriş modülüne ait arıza tespiti ve onarımlar, yalnızca SENS firmasının satış sonrası servis birimi ya da firma tarafından önerilen yetkili temsilci tarafından yapılmalıdır.

Teknik Özellikler

Uyumluluk	EN 54-18, 54-17
Besleme gerilimi:	27V
Normal akım tüketimi	1mA @ 27V
Alarm akımı	1.6mA @ 27V
Sıcaklık aralığı	-10 ila 70 °C
Nem	95% (Yoğuşma olmadan)
Boyut	20×55×90 mm
Ağırlık	60gr

